

Detail for wall ties adjacent to reveal

SureCav Ltd. www.surecav.com

Tel: 01963 34660

This procedure will prevent slots having to be made in the SureCav sheet on each course of block work when building away from a doorway or window reveal.

It is recommended that an additional wall tie is included within 225mm of the opening on each board coarse level to satisfy the structural requirements.

The ties should then be fitted every 450mm vertically coinciding with the joint in the SureCav sheet.

