




**NOTES**

1. Independent lintel to suit stone depth
2. Install DPC over lintel and tuck into breather membrane and seal slot.
3. Trim the SureCav to meet the lintel/DPC



SureCav25

TITLE

**SURECAV25 DETAIL WITH LINTELS  
FOR TIMBER FRAME/SIPS**

DRG NO.

**CA-030518-2**