



NOTES

1. The intumescent barrier must be placed so as not to interfere with the SureCav panels, either horizontally or vertically, depending on the protection required.
2. Always maintain a gap in the SureCav panel to match the width of the intumescent strip.
3. Always fix the intumescent fire-stop to the timber-frame according to the manufacturer's instructions.
4. The intumescent fire-stop illustrated is approx. 4mm deep to allow a continuous air flow in the cavity in normal conditions.
5. Only fit products that comply with local Building Regulations.



SURECAV25

TITLE

SURECAV25 WITH INTUMESCENT FIRE-STOP

DRG NO.

CA-140417-1