



NOTES

1. SURECAV IS NOT A TANKING SYSTEM. ENSURE OUTER LEAF IS SUITABLY TANKED IF BELOW GROUND LEVEL.
2. ALWAYS FIT THE FLAT SURFACE AGAINST THE OUTER LEAF, WITH THE PODS TOUCHING THE INSULATION.
3. FIT THE TIES THROUGH THE FLAT FACE OF THE SURECAV ONLY USING THE SEAL WASHERS
4. OTHER TIE SYSTEMS SUCH AS HELICAL TIES MUST ONLY BE FIXED THROUGH THE FLAT FACE OF THE SURECAV SHEET INTO THE OUTER LEAF.



SURECAV25
(Similar procedure with SureCav50)

TITLE

SURECAV DETAIL USING SURECAV25 TO SHOW CONSTRUCTION
OF INNER LEAF WHERE THE OUTER LEAF HAS BEEN BUILT FIRST

DRG NO.

CA- 031215-1