




NOTES

1. INSTALL THE SURECAV SHEET WITH THE PODS AGAINST THE INSULATION OF THE ICF.
2. THE TIES ARE SCREWED INTO THE VERTICAL FIXINGS OF THE ICF, COMMONLY BUILT IN TO THE FORMERS EVERY 8" (204mm).
3. REFER TO THE DESIGNER/STRUCTURAL ENGINEER FOR THE APPROVED CENTRES FOR FIXING THE TIES ON YOUR PROJECT.
4. TRIM THE HORIZONTAL JOINING STRIP UP TO THE TIE, CONTINUING WITH THE OFFCUT THE OTHER SIDE. THE VERTICAL JOING STRIPS ARE ALREADY CUT TO THE CORRECT LENGTH.



FIXING INSTRUCTIONS  
(ALSO SUITABLE FOR SURECAV50)

TITLE

INSULATED CONCRETE FORMER  
WITH SURECAV25

DRG NO.

CA-251119-1