SureCav Limited
Holbrook Lodge, Holbrook, Wincanton, Somerset. BA9 8BT
Tel: 01963 34660 Fax: 01963 32441
info@surecav.com www.surecav.com

Install cavity tray at natural stone/block continuation to outer leaf

Where the natural stone lower part of the outer leaf continues with an upper contrast of block and render (or other finish), a cavity tray should be installed at the head of the natural stone. Trim the SureCav sheet to meet the tray in the usual way.

SureCav® recommends **Cavity Trays** for all your waterproofing and ventilation requirements.

Cavity Trays Ltd., Yeovil, Somerset BA22 8HU www.cavitytrays.com

Copyright © 2014 SureCav Limited