SureCav Limited
Holbrook Lodge, Holbrook, Wincanton, Somerset. BA9 8BT
Tel: 01963 34660 Fax: 01963 32441
info@surecav.com www.surecav.com

Fixing a timber frame tie through the back of a SureCav pod

2. Looking into the open pod face the fixing

3. If additional fixings are required and ties are not needed then just fix the Surecav panel through the back of the pod using a screw, seal and washer as shown below.

Technical drawings

SureCav_additional_ties_1.pdf

SureCav_additional_ties_DWG.zip

More information

Phone now: 01963 34660

Contact us with a specific question

Note: Sealing washers can now be purchased from SureCav Ltd.
See our web site for details

It is important that only recommended seal washers and screws are used for this type of fixing to ensure the panel remains watertight. Used in conjunction with a timber frame tie, the assembly is screwed through the back of the SureCav pod into the timber frame sheathing. This will provide additional tie positions for the random stonework or flint.

If the screw is solely used for supporting the SureCav panels during construction, only the seal washer and screw need be used.

Always use best building practice that conforms to local authority regulations.

Copyright © 2014 SureCav Limited