SureCav Limited
Holbrook Lodge, Holbrook, Wincanton, Somerset. BA9 8BT
Tel: 01963 34660 Fax: 01963 32441
info@surecav.com www.surecav.com

Install SureCav® in a gable end parapet with pitched roof

Trim the SureCav® panel to the cavity closer. Install air vents in the outer leaf, ensuring the vent is cut through the flat area of the SureCav panel and not through the pod. The parapet up-stand shown in this illustration lends itself to the use of an S type soaker or custom lead soaker made up on site.

SureCav® recommends **Cavity Trays** for all your waterproofing and ventilation requirements.

Cavity Trays Ltd., Yeovil, Somerset BA22 8HU www.cavitytrays.com

Always use best building practice that conforms to local authority regulations.

Copyright © 2014 SureCav Limited