SureCav Limited
Holbrook Lodge, Holbrook, Wincanton, Somerset. BA9 8BT
Tel: 01963 34660 Fax: 01963 32441
info@surecav.com www.surecav.com

Trimming SureCav® to meet a lintel with timber frame construction

Install the timber frame lintel using the standard fittings and ensure that a tray or DPC is installed before construction continues. Tuck the tray under the breather membrane at the top and seal with duct tape. The SureCav panel is trimmed to meet the tray.

SureCav® recommends **Cavity Trays** for all your waterproofing and ventilation requirements.

Cavity Trays Ltd., Yeovil, Somerset BA22 8HU www.cavitytrays.com

Always use best building practice that conforms to local authority regulations.

Copyright © 2014 SureCav Limited